



ONLY ONE - BUT FUN!

QUAX

ASSEMBLY!



CONGRATULATIONS FOR HAVING BOUGHT YOUR PROBABLY BIGGEST BIKE EVER! YOUR BIKE WILL COME OUT OF THE BOX LIKE THIS - UNPACK AND UNWRAP IT BEFORE BEGINNING WITH ASSEMBLY.

TURN THE FORK IN A WAY THAT IT IS CURVED FORWARDS. THEN, INSERT THE FRONT WHEEL AND FIX IT FIRMLY ON BOTH SIDES WITH THE BOLTS.

INSERT THE STEM, CENTER ADJUST IT AND FIX IT WITH THE BOLT ON TOP OF IT.



WARNING! TAKE CARE NOT TO PULL OUT THE STEM OVER THE MINIMUM INSERT-MARK ON THE STEM. FIX THE BELL ON THE HANDLEBAR NEAR THE GRIPS.

NOW, FIX THE FRONT MUDGUARD ON THE FORK-CROWN AND ON BOTH SIDES OF THE BOTTOM OF THE FRAME WITH THE SCREWS OUT OF THE LITTLE BOX.



BOTH PEDALS AND BOTH CRANKS ARE MARKED "R" FOR RIGHT CRANK AND "L" FOR LEFT CRANK. MAKE SURE TO MOUNT THE MATCHING PEDAL. THE RIGHT ONE IS FIXED CLOCKWISE, THE LEFT ONE COUNTER-CLOCKWISE. TAKE A 15 MM WRENCH AND TIGHT FIRMLY ON BOTH SIDES.



PUT THE SADDLE FULLY ON THE SEATPOST ADJUST IT AND FIX IT WITH A 13MM WRENCH.



FIX THE BOTTOM OF THE INNER BRAKE-CABLE (OUT OF THE LITTLE BOX) IN THE BRAKE LEVER. THEN INSERT OUTER CASING.



REPEAT OPERATION FOR OTHER BRAKE-LEVER. THEN FIX THE CABLE IN THE BRAKE LIKE ON THE PICTURE ON THE LEFT. IF YOU HAVE NO EXPERIENCE IN BIKE-ASSEMBLY, GO TO A BIKE SHOP AND ASK AN EXPERT, IT'S FOR YOUR OWN SAFETY!

ENJOY YOUR FIRST RIDE ON 36"!

WWW-QU-AX-DE INFO@QU-AX-DE

FINISHED!